






**⚠ ATTENTION:** Read the instructions prior to installation.

#### Components:



1 x Locking ring

#### Tools required:



59-61mm  
Hole cutter




Power drill


#### Critical safety information:

- Prior of use, please examine and verify that the product is not defected. Please do not install or operate if there is a defect of any kind.
- If in any case you are facing misunderstanding of installation procedure, the installation should be carried out by certified electrician
- Make sure you are installing the product on smooth straight surface. Do not install in any case that the surface is not straight or if there are levels differences.
- Make sure water will not penetrate into the unit. In any case please make sure you are installing the unit, where proper leakage protection device is connected.


#### Installation:




Drill hole into the surface in cut out of 60mm. Please keep 2.5cm between the edge of the surface to the hole. Make sure that there is enough space beneath the surface for the Innera Torre .



Remove the locking ring by rotating it clockwise.




Full removal the locking ring.







Insert the Innera Torre into the hole.

#### Options:



Tight the locking ring by turn it counterclockwise until it is tighten strongly to the surface and verify the Innera Torre is firm and cannot be rotated.



#### Cleaning:

The product can be cleaned by a soft and dry fabric. Please do not use moisture, abrasives materials, solvents or any detergents which can be conductive